morphy richards

Vacuum cleaner - 73106

Please read and keep these instructions



Getting the best from your new cleaner...

2year guarantee
2 años de garantía | 2 ans de garantie

www.morphyrichards.co.uk
www.morphyrichardsindia.com

Important safety instructions

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance! In addition we offer the following safety advice.

Location

- Do not use or keep this product outside when it is raining.
- Do not store the appliance near hot ovens or heating appliances.

Main lead

- Do not allow the mains lead to become strained or run this appliance over it.
- If the electrical cable becomes damaged the complete cable assembly must be replaced. Do not attempt this task yourself, contact Morphy Richards Service Centre.

• Children

- Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.

Other safety considerations

- Never use the appliance without the filters installed.
- Never use appliance to vacuum hot ashes, broken glass, sharp objects or liquids.
- Never use in the presence of explosive liquids or vapours.
- Never pick up inflammable or poisonous liquids such as petrol, copier toner, or other volatile substances. Never pick up acids, asbestos or asbestos dust.
- Always disconnect the appliance from the mains supply after use or prior to cleaning or replacing filters.
- The appliance should never be left running unsupervised.
- Never modify the cleaner in any way.
- Repairs to electrical appliances are only to be undertaken by trained personnel unprofessional repairs can be dangerous for users.
- Use only genuine Morphy Richards spare parts and accessories

Electrical requirements

Check that the voltage on the rating plate of your charger unit corresponds with your house electricity supply which must be A.C. (alternating current).

For appliances with fitted plug

If the socket outlets in your home are not suitable for the plug supplied with this appliance the plug should be removed and the appropriate one fitted.

Warning: The plug removed from the mains lead, if severed, must be destroyed as a plug with a bared flexible cord is hazardous if engaged into a live socket outlet.

Features:



1. On/off power switch
2. Hooks for carrying strap
3. Hose inlet
4. Dust compartment (opens from beneath)
5. Exhaust filter cover with blower function
6. Dust compartment release button
7. Carry handle
8. Hose

Accesories

9. Hose adaptor
10. Crevice nozzle (fits directly onto vacuum)
11. Carry strap
12. Brush nozzle (fits directly onto vacuum)
13. Blower adapter
14. Air bed inflater nozzle
15. Medium nozzle
16. Large nozzle
17. Hose handle with air bleed
18. Extension tubes x3
19. Floor nozzle
20. Turbo nozzle (pets model only)
21. Accessory bag
22. Hepa filter
23. Mesh filter cover
24. Long brush nozzle
25. Pre-motor filter (Not featured on this page, see page 7)
26. Exhaust filter (Not featured on this page, see page 7)

Quick start

1 Assemble the desired accessories as shown on page 5.
2 Unwind the cable to it's full length and plug in to the mains supply.
3 Switch on by pressing the on/off power switch.

Accessories

1 Fit the hose to the cleaner by first inserting the hose adapter ❾ to the hose inlet. ❸ Attach the hose to the hose adapter. **A**



2 The brush nozzle ⓬ and crevice nozzle ❿ can be fitted directly into the hose inlet. without the need for hose adapter. **B**



To store the brush nozzle and crevice nozzle, insert brush nozzle vertically into clip then slide crevice nozzle horizontaly until it clips into place. **C**

3 All the other accessories attach to the hose. The extension tubes ⓲ can be attached to the hose using the hose handle for floor cleaning or extra reach.



Carry strap ⓫

Your vacuum cleaner comes with a carry strap for added convienience.

The carry strap can be clipped on the two hooks ❷ one at rear of the handle and the other in front of the on/off switch.

Floor Nozzle ⓳

The floor nozzle adjusts to suit either carpet or hard floor.**D**

Press down on the symbol for hard floors or press down on the symbol to retract the brushes for use on the carpet.



Turbo Nozzle ⓴ (pets models only)

The turbo nozzle is ideal for use on carpets or upholstery to remove stubborn pet hair. Attach to the turbo nozzle directly to the hose handle ⓱ to remove stuborn pet hairs from upholstery or small areas of carpet. (Turbo nozzle is designed for small areas only for example pet beds and chairs)

WARNING Do not attach the turbo nozzle to the extension tubes.

Cleaning turbo nozzle
(pets models only)

If the turbo nozzles rotating brush becomes entangled with hair it may require taking apart and cleaning

1 Unclip the top half of the nozzle by pulling the upper casing out slightly & lifting off. **E**



Clear out any blockages /pet hair, remove all components.and clean if necessary.

2 The main turbo wheel has a removable collar, this must be re-assembled correctly, other wise the nozzle will not go back together.

3 To re-assemble nozzle, take the brush bar with the toothed belt positioned over the track on the bar (notice the rectangular locators on either side of the brush bar). **F**



Slot the brush bar into the relevant tracks on either side of the lower casing. Ensuring that the turbo wheel is correctly placed, loop the toothed wheel through the belt and lower the turbo wheel into the grove, provided in the lower casing. The internal assembly should be complete.



4 Ensuring that the brush bar, the turbo wheel and the belt are correctly located and positioned, take the top casing and position the slots over the teeth at the front of the lower casing and clip back into position.

After re-assembly fit turbo nozzle on unit and ensure the brush bar is rotating correctly.

Assembling the product

Assembling Assembly

Vacuum



Note Make sure the correct end is fixed to the blower adapter, (smooth end).

Nozzle

When using the brush nozzle 20 to get extra suction place your finger over the hole. This is only for vacuuming. **H**



Dust disposal

To obtain the best results from your cleaner be sure to check and empty the dust compartment regularly, otherwise the airflow and cleaning power will be reduced and you may damage your cleaner.

1 Ensure the cleaner is switched off and disconnected from the mains supply.

2 Hold over a dustbin and press in the dust compartment release button ❻ , the dust compartment door will automatically drop down. Shake the vacuum to release the dirt and make sure it is completely empty. **I**

Hepa Filter cleaning

Warning: The dust compartment must be emptied BEFORE the Hepa filter is removed. Every time you empty the cleaner the Hepa filter must be cleaned.

1 Once the dust compartment is empty, remove the pleated hepa filter ㉒ & mesh filter ㉓ by pushing the tab to release. **J**

2 Pull the pleated hepa filter ㉒ out of the mesh filter cover ㉓ & clean both by gently brushing over the dustbin. Wash the filters regularly in warm water. **K**







Leave to air dry thoroughly before replacing into the cleaner.

DO NOT USE DETERGENTS

3 Replace the pleated filter into the mesh filter cover



Making sure the yellow tab on the Hepa Filter moulding is adjacent to the clip on the mesh filter cover **L** and replace back into the cleaner. Ensure the hepa filter is securely fitted back into place.

Blocked filters will reduce the airflow to the motor, should the airflow become substantially blocked, the product will then be liable to overheat and the thermal fuse will activate. Should this activate, the product will stop functining, unplug the product and allow it to cool down (ths can take between 30-40 minutes depending on the ambient temperature conditions).

Inserting Hepa Filter M

Warning: Make sure that the Hepa filter has been placed in correctly.



DO NOT USE THE PRODUCT WITHOUT THE HEPA FILTER FITTED.

IMPORTANT

- All filters should be checked regularly for signs of damage, preferably after each cleaning task. The filters must be replaced immediately if they become

- Always disconnect the cleaner from the mains when checking or replacing the filters.
- Always make sure the filters are fitted correctly before use. Failure to do so may result in damage to your product.

Pre Motor Filter

The pre-motor filter ㉕ can be found by opening the dust compartment ❹ using the dust compartment release button ❻

Remove pleated hepa filter ㉒ and mesh filter.㉓ Remove the pre-motor foam filter ㉕ from its securing tabs and clean or replace.

Replace the foam filter ㉕ over the small tabs making sure it's located correctly. **N**

Exhaust Filter O

The exhaust-filter ㉖ must be cleaned regularly to remove the fine dust particles collected. This can be done by shaking it.

The exhaust filter is located behind the exhaust filter covers ❺. To remove, push down on the tab and remove the cover. Pull out the foam filter ㉖ & clean or replace.



Using the blower function

1 Remove the exhaust filter cover ❺ and foam exhaust filter ㉖

2 Push and twist clockwise **P** the blower connector ⑬ into the back of the cleaner to lock into place.

3 Attach the hose ❽ to the correct end of the blower connector ⑬ .

4 The blower function can be used for a variety of uses including blowing dust from delicate surfaces and also drying pet fur.

If using to dry pet fur:

- **Never use the product in a wet environment.**
- **Do not use if the animal is frightened or distressed.**
- **Never leave the product alone with the animal. Never allow the animal to chew the product.**



Technical Data

Power Supply	: AC 230V 50Hz
Wattage	: 800W

Morphy Richards products are intended for household use only

Morphy Richards has a policy of continuous improvement in product quality and design. The Company, therefore, reserves the right to change the specification of its models at any time.

Products & parts are indicative only, the actual product may differ.

morphy richards

Morphy Richards Ltd, Mexborough,
South Yorkshire, England, S64 8AJ